



WARNING:

Risk of electric shock. Before installation, disconnect power to the luminaire. Failure to do so may result in electric shock and lead to injury or death.
Risque de choc électrique. Avant l'installation, débranchez l'alimentation au luminaire. Ne pas le faire peut entraîner un choc électrique et entraîner des blessures, voire la mort.

CAUTION:

For your safety, read and understand instructions completely prior to installation. Installation requires knowledge of luminaire electrical system. If not qualified, DO NOT attempt installation. Contact a qualified electrician if necessary.
Pour votre sécurité, lisez et comprenez entièrement les instructions avant l'installation. L'installation nécessite une connaissance du système électrique des luminaires. Si vous n'êtes pas qualifié, NE PAS tenter l'installation. Contactez un électricien qualifié si nécessaire.

NOTE: Before beginning the installation, carefully unpack and identify all parts. Save these instructions as you may need them at a later date.
This item has tight tolerances, cutouts should be made accurate and precise.

DISCLAIMER: ALL FRAMES MUST BE INSTALLED IN MIN. 1/2" DRYWALL PRIOR TO WOOD INSTALLATION.
**** IF NOT USING DRYWALL BEHIND WOOD, FRAMES MUST BE LIFTED 1/2" ****

Step 1. Install the desired housing into the drywall per its installation instructions.

Step 2. Mark the desired position onto the wood. Measure and cut a hole within the maximum cutout size, Table 1.
DISCLAIMER: This product has a tight tolerance, all holes should be measured prior to cutting.

Step 3. Align the wood ceiling adapter with the opening of the housing and place it inside of the housing to center the brackets. Make sure the countersink side of the brackets are facing towards the floor. Screw in the brackets to drywall using #8 or #10 drywall screws.

Fig. 1 and 2.

Step 4. Install the wood ceiling onto the drywall.

Step 5. Once the wood ceiling is in place, loosen the interior screws to adjust the adapter's set position. Leave around 1/8" of a gap between the bottom of the adapter and the ceiling. **Fig. 3.**

Step 6. Install the trim and verify the trim's face is flush to the ceiling. Adjust as needed.

Table 1. Maximum Cutout Size

EL3WCARD	EL4WCARD
Ø3 - 3/16" Ø81mm	Ø4 - 1/32" Ø103mm

